INSTRUCTION# 6478

INSTALLATION OF GTP-9657 AIR CYLINDER ASSEMBLY SERVICE KIT.

NOVEMBER 12, 2021

NOTE: FOR BEST PERFORMANCE, ALL ITEMS WITHIN THIS SERVICE KIT MUST BE USED.

TOOLS REQUIRED: 1. PICK 2. 5/32" HEX KEY 3. GTP-9424 THREAD SEALANT (SUPPLIED)

DISASSEMBLY

- 1. REVIEW THE DRAWING ON THE NEXT PAGE.
- 2. WITH A PERMANENT MARKER, MARK THE END OF THE SHAFT ON THE SIDE OF THE CYLINDER WITH THE CAP ETCHED GTP-9657.
- 3. CAREFULLY REMOVE THE FOUR BOLTS WITH THE 5/32" HEX KEY. DISPOSE OF THEM.
- 4. WHILE HOLDING THE CYLINDER, GENTLY REMOVE ONE END CAP FROM THE ASSEMBLY.
- 5. REMOVE THE CYLINDER FROM THE OTHER END CAP.
- 6. REMOVE THE PISTON AND SHAFT ASSEMBLY FROM THE CYLINDER.
- 7. REMOVE THE TWO SEALS FROM THE PISTON. USE THE PICK TO ASSIST WITH THIS IF NEEDED.
- 8. USING THE PICK, REMOVE THE SEAL THAT IS BETWEEN THE TWO BUSHINGS IN EACH END CAP. **BE CAREFUL TO NOT GOUGE THE BUSHINGS.**
- REMOVE THE VEGETABLE FIBER GASKETS IN THE OUTER GROOVE OF EACH END CAP.

INSTALLATION

- 1. INSTALLATION IS REVERSE OF ABOVE.
- 2. ENSURE THE PISTON AND ROD SEALS ARE PLACED IN THE DIRECTION AS INDICATED ON THE DRAWING IN THE NEXT PAGE.
- 3. LIGHTLY LUBRICATE ALL MOVING PARTS WITH VASELINE PRIOR TO ASSEMBLY.
- 4. THE MARKED END OF PISTON SHAFT ASSEMBLY MUST BE INSTALLED IN THE END CAP ETCHED GTP-9657.
- 5. PLACE A FEW DROPS OF GTP-9424 THREAD SEALANT ON EACH OF THE THREADS OF THE FOUR BOLTS PRIOR TO ASSEMBLY.
- 6. AFTER ASSEMBLY IS TOGETHER, TIGHTEN EACH OF THE FOUR BOLTS IN A CRISS-CROSS PATTERN UNTIL THEY REACH 40 IN/LBS.
- 7. ENSURE THE SHAFT CAN MOVE BACK AND FORTH WITH VERY LITTLE EFFORT.

TITEM QTY PART NUMBER DESCRIPTION 1 2 GTP-9657-16 PISTON SEAL 2 2 GTP-9657-17G GASKET 3 2 GTP-9657-18 ROD SEAL 3 - OPEN ENDS FACE INSIDE OF CYLINDER TITEM QTY PART NUMBER DESCRIPTION 1 2 GTP-9657-16 PISTON SEAL 2 1 GTP-9657-17 GASKET 3 - OPEN ENDS FACE INSIDE OF CYLINDER 1 - END CAP	
1 2 GTP-9657-16 PISTON SEAL 2 2 GTP-9657-17G GASKET 3 2 GTP-9657-18 ROD SEAL 3 - OPEN ENDS FACE INSIDE OF CYLINDER Tend cap	
2 2 GTP-9657-17G GASKET 3 2 GTP-9657-18 ROD SEAL 3 - OPEN ENDS FACE INSIDE OF CYLINDER 1 - END CAP	
3 2 GTP-9657-18 ROD SEAL 3 - OPEN ENDS FACE 1 END CAP	
3 - OPEN ENDS FACE 1 END CAP	
BUSHINGS	AFT
BREAK ALL SHARP EDGES DIMENSIONS ARE IN INCHES TOLERANCES: TOLERANC	5
DECIMAL: ± 1/32 DECIMAL: X.X ± .05 X.XX ± .01 TITLE PAGE 2 OF 2: INSTRUCTION 6478; SEAL ORIENTATION	N
PROPRIETARY AND CONFIDENTIAL X,XXX ± .005 FOR GTP-9657 AIR CYLINDER	
DRAWING IS THE SOLE PROPERTY OF ANGULAR: ± 1° SIZE CAGE CODE DWG NO	REV
REPRODUCTION IN PART OR AS A WHOLE A 32218 GIP-9657-INSTRUCTIONS	0
WITHOUT THE WRITTEN PERMISSION IS PROHIBITED. DRAWN 10/27/2021 SCALE MATERIAL SHEET 1	OF 1