

PRIMING THE VIPER PUMP



The Viper pump should only need to be primed on initial startup, the additive tank has run dry or after replacing the check valve o-rings.



Remove both priming port plugs.
An Allen wrench is required.





Use a squeeze bottle to fill both priming ports.
Apply Teflon tape to the priming plugs.
Coat the Teflon tape with petroleum jelly.
Thread the priming plugs into the pump body and tighten.
The pump is now ready to be used.